


MAIN SWITCHBOARD

Located on outside wall adjacent to games room external door



OPENING LODGE

1. Turn on all switches. Ensure all switches are up
2. Turn water on in laundry as per instruction sheet 10.

CLOSING LODGE

1. Turn all switches down EXCEPT 9, 10, 11 & 15, which are always left on.

Revised May 2019