

# 11A HEATING


**A. CEILING HEATING - LOUNGE & DINING AREAS.** There is one heating system in the ceilings of the kitchen, living, and dining area. This is controlled by the two wall mounted control panels to the left of the hall door. Unfortunately, these controllers are complex. It is best to leave the system on in the \* position (the little black button at the bottom of the controller). If it is turned off, ie the switch moved to the left, the time setting will default to 12 pm when turned on again the pre-programmed time program will become out of synch with the actual time. **Please ensure that the time shown on the display is always the correct time.** This will allow the system to operate correctly under the morning and evening time schedules. Each time the switch is turned off the time setting needs to be reprogrammed from 12 pm!

**If all else fails instructions are provided on the next pages for reprogramming.**

## **B. GAS FIRED HEATER – LOUNGE ROOM**

This heater is set on MANUAL mode and the room temperature is controlled by you.

The heater is NOT INSTANT RESPONSE to your request be patient and it will happen. (May take up to 3 or 4 minutes for initial startup.)



To operate on HIGH – switch BOTH switches on (down) – heater will start up in a few minutes.

To operate on MEDIUM – switch RIGHT HAND switch on (down).

To operate on LOW – switch LEFT HAND switch on (down).

**VERY IMPORTANT----- To change from LOW to MEDIUM or MEDIUM back to LOW you must switch the other switch on FIRST so both switches are on THEN turn off the switch you don't require. Should this not be done the heater may require reprogramming.**

### **PLEASE TURN OFF GAS FIRE BEFORE GOING TO BED**

THE CONTROL PANELS ON THE WALL BESIDE THE DOOR TO THE HALLWAY HAVE NOTHING TO DO WITH THE GAS HEATER.

**BEDROOMS & GAMES ROOM** See separate instructions “11B Room Heating Thermostat”. Please turn all heaters off in the mornings to save electricity costs.

**AIRLOCK.** The lodge front door and the next door at the foot of the stairs should be kept closed to conserve the heat inside the lodge during the winter months.

**DOUBLE GLAZING** throughout serves to help keep these areas warm. Please use the gas fire in the evenings for additional heating. Lowering the curtains helps retain heat at night.

